

Coil Over Shock Orientation

The AVO shocks supplied with the Stalker have descriptive part numbers.

The 120/085 (12 " extended / 8 ½" compressed)are for the front .

Front Springs are 275 #

Adjusters should be " down "



130/090 13" shocks go to the rear, also adjusters down. The rear axle will rest on the frame when the car is jacked up. A ¼" rubber bump stop should be attached to the frame . Springs 200#

